




## Roof Zones

### NOTE

Note: Please refer to your current local county for individuals roof zone according to address

### TABLE

Zone 1: Field  
Zone 2: Perimeter  
Zone 3: Corner



## Determining Perimeter (Zone 2) and Corner (Zone 3) Areas:

**Dimension 'a'** = The lesser value of 10% of the "Lesser Plan Dimension" or 40% of the Mean Roof Height ( $0.1 \times$  "Lesser Plan Dimension" or  $0.4 \times$  Mean Roof Height)

### NOTE

Dynamic Metals recommends minimum 4 feet wide in any direction for your corner and perimeter conditions.  
Every roof is different, please consult the current Florida Building Code.